

EC942 User's Manual

Edge Computer EC940 Series User's Manual

(Applicable for Debian10,IEOS V2.0.0 and above)

Version2.0, October 2023

www.inhandnetworks.com



The software described in this manual is provided according to the license agreement and can only be used according to the terms of the agreement.

Copyright Notice

© 2023 InHand Networks.All rights reserved.

Trademarks

The InHand logo is a registered trademark of InHand Networks.

All other trademarks or registered trademarks in this manual belong to their respective manufacturers.

Disclaimer

InHand Networks reserves the right to change this manual, and the product is subject to subsequent changes without prior notice. We will not be responsible for any direct, indirect, intentional, or unintentional damages and hidden dangers caused by improper installation and use.

1 Introduction

This user's manual is for the EC900 series of edge computers based on the Arm architecture and covers a complete set of instructions for all supported models. Before referring to these sections, verify that the hardware specifications of your computer model support the features/Settings covered.

2 Hardware installation instructions


In this chapter, we will cover the hardware installation instructions for the EC900 series of edge computers based on the Arm architecture.

2.1 Introduction


The following sections describe the application of external connectors and pin distribution of the EC942 series, using the EC942 series as an example.

2.2 EC942 panel

Right panel



Front panel



2.3 EC942 external connector

2.3.1 Ethernet

This is a dual RJ45 connector for Ethernet connection


The EC942 has 2 RJ45 Ethernet ports and supports 10M/100M/1000M adaptive rates.

Green light: LINK indicator, 1000M interface is on for the end device, and 10/100M interface is off for the end device.

Yellow light: ACT light, flashing when there is data

2.3.2 Serial port

EC942 supports two-channel serial port, support RS-232 or RS-485 or RS-422 communication, software can be configured.



DB9 pin number	Pin name	Pin Definition
1		
2	RS-232 RxD/RS-422 TxD+	RS-232 receive /RS-422 send positive
3	RS-232 TxD/RS-485 B/RS-422 RxD-	RS-232 send /RS-485 signal B/RS-422 receive negative
4		
5	GND	RS-232 ground
6		
7	RS-485 A/RxD+	RS-485 signal A/RS-422 receive positive
8	RS-422 TxD-	RS-422 send negative
9		

2.3.3 CAN

EC942 has 1-way CAN bus interface and supports CAN 2.0A/B standard. It is compatible with CAN FD and can achieve a maximum rate of 5Mbps.

Signage	Features
CAN_H	CAN high level data line
CAN_L	CAN low level data line
GND	to

2.3.4 Switching Input interface (Digital Input)

Interface identification	Features	Description
PCOM	Power common terminal	4-way digital input DI,

DGND	Power reference ground	Dry contact state
DICOM	Input public side	"1" : Closed dry contact state "0" : disconnected
DI0	Digital input port 0	Wet contact state "1" : +10~+30V/-30 ~ -10VDC
DI1	Digital input port number 1	Wet contact state "0" : 0 ~ +3V/-3 ~ 0V
DI2	Digital input port number 2	Isolate 3000VDC
DI3	Digital input port number 3	
NC	There is no	

2.3.5 Switching Output interface (Digital Output)

Interface identification	Features	Description
DO0	Digital output port 0	4 digital output DO, Isolated 3000VDC
DGND	Ground end	
DO1	Digital output port number 1	
DGND	Ground end	
DO2	Digital output port 2	
DGND	Ground end	
DO3	Digital output port No. 3	
DGND	Ground end	

2.3.6 USB

The EC942 provides two USB 2.0 Host ports.

2.3.7 LED

EC942 has 12 LED lights to indicate the power supply and system operation status respectively.

Signage	Name	Definition
PWR	Power indicator	Power on and always on
STATUS	System operating status indicator light	When the system starts normally, the STATUS blinks. If the system fails to start due to an exception in the system startup phase; Or when the factory recovery operation has not been completed, STATUS is long out.
WARN	Warning indicator light	The WARN light flashes when there is a warning exception in the system and the system upgrade or factory restoration has not been completed.
Error	Error indicator light	When a serious system Error occurs and the system upgrade or factory restoration has not been completed, the Error light blinks.
SIM1	SIM1 card indicator,	Select SIM card 1 for dialing, select SIM card 2 for dialing or turn off dialing, long off.
SIM2	SIM1 card indicator light, always on if selected	When SIM card 2 is selected for dialing, it is always on. When SIM card 1 is selected for dialing or dialing off, it will be long off.
User1	User Programmable indicator 1	It is off by default and can be controlled by user programming
User2	User Programmable indicator light 2	It is off by default and can be controlled by user programming
4G/5G	Cellular connection status indicator	Keep on after successful dialing
L1	Cellular signal strength	See Cellular Signal Strength Indicator instructions

L2	Cellular signal strength
L3	Cellular signal strength

Cellular signal strength indicator

LED	No signal	Weak signal (RSSI < -90)	Moderate signal (-90 <= RSSI < -70)	Strong signal (RSSI >= -70)
L1	destroy	bright	bright	bright
L2	destroy	destroy	bright	bright
L3	destroy	destroy	destroy	bright

In addition to the combination of L1, L2, L3 signal lights to indicate cellular signal strength, there is also a set of LED combinations to mark the process of restoring the factory.

LED	State
WARN	Twinkle
ERROR	Flashing
STATUS	Put out

After executing the restore factory Settings, the system will perform a restart, after the restart is completed, the restore factory is not completed, at this time WARN light and ERROR flashing, STATUS off, in this state can not power off the device, otherwise it may lead to the loss of some files and affect the system function. This state will last for 30 seconds, when the factory recovery is completed, WARN and ERROR will go off, and STATUS will flash.

2.3.8 User programmable keys

EC942 provides API interface, the user can call the API interface to detect the state of the programmable key, and then implement their own key logic.

2.3.9 DC input

The EC942 supports 12 to 48V DC input

2.3.10 SIM card slot

The EC942 supports 2 SIM card slots, the SIM card needs to be installed with power off, the SIM card is pressed into the slot.

2.3.11 MicroSD card slot

The EC942 has a slot for the MircoSD card, SD does not support hotplug and needs to be plugged in and out with power off. After inserting the SD card and powering up the device, the system will automatically mount all partitions.

2.3.12 Restore factory keys

There is a reset button for the system to restore the factory. Refer [to Restore Factory Settings](#) to do so.

2.3.13 Switch the machine button

EC942 is equipped with an on-off button for switching the machine on and off.

2.3.14 Antenna interface

There are 5 antenna interfaces in EC942, and the number of antennas standard with different models is different. The antenna is screwed into the corresponding antenna interface to complete the antenna installation.

logo	Name
ANT1	4G LTE main antenna /5G antenna
ANT2	4G LTE diversity receive antenna /5G antenna
GNSS	GNSS antenna
ANT3	5G antenna
ANT4	5G antenna
WiFi1	WiFi antenna
WiFi2	WiFi antenna

2.3.15 Dial switch

The dial switch controls the pull up and pull down resistance of the 485 bus. The pull up and down resistance can be selected to increase the number of 485 bus loaded devices.

Identification	Functional Notes
PU	ON - enable pull-up resistor; OFF - disables the pullup resistor
PD	ON - enables pull-down resistor; OFF - disables the pull-down resistor
T	ON -- Enable the terminal to match the resistor; OFF - Disables terminal matching resistor

2.3.15 mSATA hard disk interface

EC942 supports mSata hard disk, and the factory does not come with mSata hard disk by default. If users have large capacity storage requirements, they need to buy mSata hard disk from themselves, or they can consult Inhantel for mSATA purchase.



3 Getting Started

In this chapter, we will cover the basic configuration of EC900, an edge computer based on Arm architecture.

3.1 Connect to the EC900

You will need a computer that you can use to connect to the EC900 and log in to the command-line interface. It can be connected by means of an Ethernet cable.

Factory default username and password:

Username: edge

Password: security@edge

EC900 devices are factory created root by default, but login is disabled. If you need to use the root user, change the system configuration manually and type `sudo -s` to switch to the root user. The user `edge` is in the `sudo` group, so you can use `sudo` under the `edge` user to execute system-level commands. See the `sudo` Mechanism section in Chapter 5 for additional details.

Tips

When **command not found** appears, type `sudo -s` to switch to the root user or use the `sudo` command to operate.

Note

For security reasons, we recommend that you disable the default user account and create your own.

3.1.1 Connecting via the SSH Console

The EC900 supports SSH connections over Ethernet. Connect to the EC900 using the following default IP address.

Port	Default IP
ETH 1	192.168.3.100
ETH 2	192.168.4.100

3.1.1.1 Linux users

Tips

These steps apply if you are connecting to EC900 on a Linux PC. Please do not apply these steps to the EC900 device itself. Before you run the `ssh` command, be sure to configure your PC's Ethernet port IP address to be within a specific range. `ETH1:192.168.3.0/24`, `ETH2:192.168.4.0/24`.

Use the `ssh` command to access the ETH1 port of the EC900 on a Linux PC.

```
user@PC:~$ ssh edge@192.168.3.100
```

Type **yes** to continue to complete the connection.

```
The authenticity of host '192.168.3.100 (192.168.3.100)' can't be established.
ECDSA key fingerprint is SHA256:jqilREbTX6Ut2whNFdpLvCcQfM3KUnl3Ta7/dWppBCU.
Are you sure you want to continue connecting (yes/no)? yes
```

When the terminal prompt `edge@edge-computer:~$` appears and shell commands can be entered, the connection is successful.

```
?IIIII      ?I  IIIIIIIIIII?      ?III
  IIII      IIII  ?IIIIIIIIIIIIIIIIIIII
    ?III     7IIIIIIII  IIIIIIIIIIIIIIIIIIIII
      II     I?IIIIIIIIII  IIIIIIIIIIIIIIIIIIIII
            IIIIIIIIIII?  ?IIIIIIIIIIIIIIIIIIII
            ?IIIIIII      ?IIIIIIIIIIII?

II
II          ?b                      Ib
            ?II                      IIN
II  I?IIIII  ?IIIII?  IIIIII  IIIIIII  $?IIIIIN
II  IIIIIIII  ?IIIIIII  ?IIIIIII  IIIIIIII?  IIIIIIIIN
II  II?  IIN  III  II  II  II  OII 8II  IIN
II  II?  IIN  III  II  III??II  II  II 8I?  IIN
II  II?  IIN  III  II  ZIIIIIIII  II  II 8I?  IIN
II  III  IIN  III  II  II?  II  II  II 8I?  IIN
II  III  IIN  III  II  ?II  II  II  II  II$  IIN
IIIIIII  IIIIIIII  II  ZIIIIIIIIII  II  7IIIIIIIN
      IIN
      IIN
      IIN
      IIN
      IIN
      NN

For further infomation check:
https://www.inhand.com.cn/ or https://www.inhandnetworks.com/

Last login: Tue Jan 17 16:48:58 2023 from 192.168.4.5
edge@edge-computer:~$
```


3.1.1.2 Windows users

Tips

These steps apply if you are connecting the EC900 on a Windows PC. Please do not apply these steps to the EC900 device itself.

Make the following steps on your Windows PC

Click the link <http://www.chiark.greenend.org.uk/~sgtatham/putty/download.html>, download PuTTY (free) software, SSH command in Windows environment to establish a connection to the edge computer EC900. The following is an example of using SSH to connect:



3.2 User Account management

3.2.1 Switch to the root user

You can use the `sudo -s` command to switch to the root user. [For security reasons, do not operate all commands as root.](#)

Tips

[Click on the link for more information on `sudo` commands.](#)

<https://wiki.debian.org/sudo>

Pay attention to

You may get a "permission denied" message when using some pipe or redirect behavior without root permissions. In this case, you must use '`sudo su -c`' instead of '>', '<', '>>', '<<', 'etc', etc. You need to include the full command in single quotes.

3.2.2 Creating and deleting user accounts

You can create and delete a user's account using the `useradd` and `userdel` commands. Be sure to use these commands in the home screen to set the relevant access rights for that account. Here is an example of how to create `test1` in the `sudo` group (the default login environment for `test1` users is `bash` and their home directory is `/home/test1`)

```
edge@edge-computer:~$ sudo useradd -m -G sudo -s /bin/bash test1
```

To change `test1`'s password, use the `passwd` command, enter the new password and repeat to confirm the change

```
edge@edge-computer:~$ sudo passwd test1
New password:
Retype new password:
passwd: password updated successfully
```

If you want to remove user test1, use the command userdel

```
edge@edge-computer:~$ sudo userdel test1
```

3.2.3 Disable the default user account

Note

You should first create a user account before disabling the default account

Use the passwd command to lock the default user account so that edge users cannot log in

```
edge@edge-computer:~$ sudo passwd -l edge
passwd: password expiry information changed.
```

Unlock the edge user

```
edge@edge-computer:~$ sudo passwd -u edge
passwd: password expiry information changed.
```

3.3 Network administration and system administration

The EC942 is based on debian 10, so native Linux commands can be used for network management and system administration; In order to facilitate user configuration, InHand has developed a set of IEOS system programs, providing a web interface, users can easily through the web network management and system management, but it should be noted that when the IEOS function is enabled, IEOS will take over the network management and system management. At this time through the Linux native command for network management and system management may fail; IEOS is enabled by default, if users need to perform network management and system management based on Linux native command line, they need to close IEOS first.

3.3.1 web Management based on IEOS

IEOS is a set of network management and system management program running on Linux system developed by InHand. IEOS provides web interface, users can access Ethernet port ip address, cellular dial-up, Wi-Fi Station, DHCP Client/Server, static routing, and network management through the web. Firewalls and other network configuration; System time, time zone, firmware upgrade and system restart can also be operated; In addition, IEOS also supports docking with InHand device management platform DeviceLive. Users can remotely monitor and manage EC942 devices through DeviceLive platform.


IEOS adopts the design scheme of status and configuration separation, which is divided into three functional sections: network management, system management and status. The network management menu and the system management menu can only be used for network and system related configuration, and the status information needs to be unified to the status page.

Important note: When using IEOS program to manage network configuration and system configuration, if you use Linux native commands at the same time, the two may affect each other, resulting in abnormal running state. It is recommended that the configuration supported by IEOS be managed through IEOS web, and the configuration not supported by IEOS, such as VPN, can be combined with native Linux commands to achieve the configuration goal.

3.3.1.1 Login to the web

Considering that the user's program may need to use the standard HTTP/HTTPS port number 80/443, IEOS uses the port number 9100 as the HTTPS connection port, and does not support access through HTTP; When the user uses HTTP to access the web, it will automatically jump to HTTPS. This document uses eth2's default address of 192.168.4.100 as an example. The user enters 192.168.4.100:9100 in the browser and is taken to the login page


Important note: When IEOS programs are enabled, some port numbers will be reserved for internal communication. The reserved port numbers range from 9100 to 9200. After IEOS is enabled, client programs should avoid using these port numbers, or it may cause conflicts and malfunction.




3.3.1.2 Network management

3.3.1.2.1 Configuring the Ethernet interface


Configure the eth1 interface with a static IP address



Configure the eth1 interface with a DHCP Client



Start the dhcp server function on the eth1 interface and assign an address to the eth1 unhooked device



DHCP Server configuration parameters description:

Enable DHCP Server: The switch of DHCP Server function

Starting Address: Starting base address of DHCP Server address pool, network segment + starting address = starting ip address of address pool. In the screenshot, the network segment of eth1 is 192.168.3.0/24, and the base address is 1, then the starting address of the address pool is 192.168.3.1/24.

Max Address Number: The maximum number of addresses in the address pool.

Lease period: The length of the lease period

3.3.1.2.2 Configure cellular dialing

The screenshot shows the configuration page for Cellular dialing. The interface includes a sidebar with navigation options like Status, Network, Interfaces, Cellular, WiFi, Static Routes, Firewall, DNS, Diagnostics, and System. The main content area is titled 'Cellular' and shows a toggle switch for 'Enabled' which is turned on. Below this is a table for 'APN Profiles' with one entry: Index 1, APN 'internet', and Auth Method 'No Auth'. Further down, there are settings for 'Network Mode' (set to 'Auto'), 'Enable Default Route' (checked), 'Metric' (set to 200), and 'Dual SIM Enabled' (unchecked). Under 'SIM1', the 'APN Profile' is set to '1' and there is a 'PIN Code' field. At the bottom, there are 'Save' and 'Reset' buttons.

Cellular network parameters Description:

Enabled: The switch of cellular function; Enabled by default.

10. Profiles: A set of dial parameters used to configure APN, username, password, and authentication methods when dialing a dedicated network card. If you are not a dedicated network card, you usually do not need to change the configuration here. You can add up to 10 records to the dial-up parameter set.

Network Mode: The network mode of the cell, you can choose 3G, 4G and other related network mode, such as LTE, WCDMA, etc. If it is not clear which network mode to choose, select automatic; The program will automatically select the most appropriate network mode. The default is automatic.

Enable Default Route: Enable the function of adding default route. When enabled, a default route of cellular port will be added when the dial is successful. The default route is enabled.

Metric: This is the metric for the default routing of the cellular port. When default routing is configured on the cellular, Wi-Fi, and Ethernet ports, the metric with the lowest value is used.

The screenshot shows the 'Dual SIM Enabled' configuration section. It features a toggle switch for 'Dual SIM Enabled' which is turned on. Below this are two columns of settings for 'SIM1' and 'SIM2'. For SIM1, the 'Main SIM' is set to 'SIM1', 'Max. Number of Dials' is set to 3, 'APN Profile' is set to 'Auto', and there is a 'PIN Code' field. For SIM2, the 'APN Profile' is set to 'Auto' and there is a 'PIN Code' field.

Dual SIM Enabled: Dual Sim enabled. In order to improve the reliability of the network, EC942 supports dual SIM and single dial. Two sim cards need to be inserted into the device. If the sim1 card fails to dial because of unpaid charges, it will automatically switch to the sim2 card for dialing. By default, it is off.

Main SIM: The main sim card, when dialing, the selected sim card will be preferred for dialing. When dialing fails to reach a certain number of times, when switching to another sim card for dialing, the default is to use sim1 for dialing.

Max Number of Dials: When the dual-SIM single-dial function is enabled, the current sim card will be dialed to another sim card for dialing when the number of dials reaches a specified number.

APN Profile: sim card selected dialing parameters set, the default value is automatic. Usually special network card usually need to configure the dial parameter set, and select the Index of the dial parameter set here.

PIN Code: The PIN code of the sim card.

ICMP Probes ▾

ICMP Detection Server Probes:

* Detection Interval: Seconds (1-86400)

* Detection Timeout: Seconds (1-86400)

* Detection Max Retries:

Detection Strict:

Wireless cellular networks are complex, sometimes there will be dial-up false connection, that is, the dial-up state is successful, but the target address can not be ping; When this happens, you can simply dial again and get back to normal. IEOS cellular dialing supports ICMP probing to detect spurious connections. **It is recommended that customers with cellular connections enable ICMP probing so that false connections can be quickly recovered.**

ICMP probe parameters:

ICMP Detection Server Probes: ICMP probe address; 2 probe addresses can be configured, as long as 1 address is successfully probed, it means that there is no fake connection in the cell. When neither address is configured, ICMP probing is turned off.

Detection Interval: How often should ICMP probes be performed?

Detection Timeout: The duration of ICMP probe timeout. If no probe response packet is received, the probe is considered to have failed

Detection Max Retries: the maximum number of probes; When a probe fails to reach this value, a redial is triggered. Range [1,5]

Detection Strict: Whether strict detection is enabled. When strict detection is turned off, the detection program will detect whether the packet received by the cellular interface has changed in each detection cycle. If there is a change, it means that the cellular network is working, and ICMP packets will not be sent for detection, so as to save some traffic; If the probe is turned on, ICMP probe packets will be sent periodically regardless of whether the number of packets received by the cellular interface has changed. By default, it is off.

Advanced Settings ▾

Debug Mode enabled:

Enable Infinitely Redial:

Dial Interval: Seconds (0-3600)

Signal Query Interval: Seconds (0: disabled)

In Advanced configuration are some less commonly used Settings options.

Debug Mode enabled: Whether the debug function is enabled. After enabled, some dial-related debugging information will be added to the log, and it is disabled by default.

Enable Redial: This enables unlimited redial. In some cases, dialing will be in an abnormal state, which can be restored by rebooting the system; By default infinite redialing is turned off, and the system will be restarted to try to recover after a certain number of dialing failures. Since dialing is enabled by default, some customers without sim card, dialing failure, the system will restart, in this case, you can open unlimited redialing; In this way, no matter how many times the dialing fails, the system will not restart.

Dial Interval; But if a dial fails, the amount of time to wait before making another dial.

Signal Query Interval: Signal query interval. When the signal is bad, you may have problems with false connections; At this time, redialing has a certain probability to solve the problem of false connection. The dialing program will check the signal strength at regular intervals; here, the signal detection period is configured.

3.3.1.2.3 Configure the Wi-Fi Station

WiFi Station

Enable Wi-Fi:

* Client SSID:

Enable Default Route:


* Metric:

Auth Method:

Encrypt Mode:

* WPA/WPA2 PSK Key:

SSID Scan

Channel	SSID	BSSID	Security	Signal(dBm)	Actions
 No data					

Enable Wi-Fi: Enable the switch; Off by default

Client SSID: The ssid you want to connect to, you can enter it manually; You can also use the scan button to get nearby SSIDs that you can connect to

Enable Default Route: Enable the function of adding default route. If enabled, when the wifi connection is successful, a default route of wlan port will be added. The default route is enabled.

Metric: This is the metric for the default route of the wifi port. When the default route is configured for the cellular, Wi-Fi, and Ethernet ports, the metric with the lowest value is applied.


Auth Method: Auth method, supports no auth, WPA-PSK, WPA2-PSK, WPA-PSK/WPA2-PSK Mixed

Encrypt Mode: encrypt mode; CCMP, TKIP, TKIP and CCMP are supported

WPA/WPA2 PSK Key: Key information

3.3.1.2.4 Configuring static routes

This is a static routing for Ethernet. When the default routing for Ethernet, cellular, and wifi is configured, the default route with the lowest metric value will take effect. You need to make sure that the Metric value of the default route is different.



Static route configuration parameters:

Interface: The outgoing interface of the static route


Target: The target network

Netmask: The target network mask

Gateway: Next hop address


Metric: The metric for the static route

3.3.1.2.5 Configuring the firewall




Only the iptables command is currently supported for configuration.

3.3.1.2.6 Configuring DNS




DNS Servers: DNS Server address, up to 4 can be configured

Domain name hijacking: Domain name hijacking function, can realize the binding between IP address and domain name.



3.3.1.2.7 Network diagnostics

Network diagnostics support ping, traceroute and nslookup functions.



3.3.1.3 System administration

3.3.1.3.1 Basic configuration

Cloud management

Cloud Management

Enabled:

* Cloud Server: DeviceLive - China (device.inhandcloud.cn) ▼

Save Reset

Enabled: the enable switch that connects to the DeviceLive platform; DeviceLive is the remote monitoring and management platform of InHand equipment;

Cloud Server: DeviceLive platform has 2 addresses; One is the address of the domestic platform, the other is the address of the overseas platform; Here you choose which platform to connect to.

Time zone and NTP client

Time

Timezone ☺: UTC +08:00 China,Hong Kong,Taiwan,Western Australia,Singapore ▼

NTP Client:

* Sync cycle: 3600 Seconds (1-36000)

* NTP Server1:	0.debian.pool.ntp.org	Port:	123	⊖
* NTP Server2:	1.debian.pool.ntp.org	Port:	123	⊖
* NTP Server3:	2.debian.pool.ntp.org	Port:	123	⊖
* NTP Server4:	3.debian.pool.ntp.org	Port:	123	⊖

+ Add a Server

Save Reset

Up to 10 NTP Server addresses can be configured, and the program periodically sends synchronization requests to each server address in turn. After the synchronization is successful, the system time is written to the RTC and no longer continues to send synchronization requests to the later NTP servers.


In addition to using NTP to synchronize the time, there is a synchronization button in the Device Info status page to synchronize the time manually, but only when the device time and the local time (the time of accessing the computer used by the device) differ by more than 3s, this synchronization button will be displayed.

Configuration File

Configuration File Import Export Restore Factory


Configuration import, export and factory restore are supported here.

3.3.1.3.2 Firmware upgrade



The automatic restart option is turned off by default. After upgrading the firmware, you need to manually restart the system to take effect; When the automatic restart option is enabled, the system will be restarted automatically after the firmware upgrade is successful.

3.3.1.3.3 Others



This page has 2 functions: restart the system and reset the system. Resetting the system needs to be used carefully. The resetting system function will restore the system configuration status and file system status to the factory, which means that the software installed by the user will also be cleared.

3.3.1.4 Status

3.3.1.4.1 Equipment information

The device information status page shows the hostname, device model, serial number, firmware version, kernel version, file system version and an overview of CPU, memory and disk space usage.

Device Information

Name: edge-computer	Model: EC942	Serial Number: CL942343000019	MAC Address: 2A:62:32:78:85:28
License Status: 小量云管家标准版	Firmware Version: V2.0.1-test.2	Kernel Version: 4.19.232	OS Version: Debian GNU/Linux 10 (buster)
Bootloader Version: 1.0.1	CPU Load Average: 0.00, 0.08, 0.13	Uptime: 19 hours, 53 minutes	Local Time: 2023-10-20 09:03:54 UTC +08:00 Sync with browser

Device Status

- CPU Usage: 7%
- Memory Usage: 355.0 MB / 3.8 GB (9%)
- User Flash Usage: 241.0 MB / 5.7 GB (4%)

3.3.1.4.2 Cellular dialing status information

The cellular dialing status page shows the sim card, IMEI, IMSI, ICCID, signal strength used by the current dialing, as well as the IP address, DNS and other information obtained by the dialing.

Modem Status

Present SIM: SIM 1	IMEI: 863674046816953	IMSI: 460026001115905	ICCID: 898600F0221109E25905
Signal Strength:	Registration Status: Network registered	Operator: CMCC	PLMN: 46000
Network Mode: LTE/TDD LTE B39	LAC: 0x8005	Celluar ID: 0x3FD4EC2	

Celluar Interface

Status: Connected	IP Address: 192.168.225.20	Netmask: 255.255.255.0	Gateway: 192.168.225.1
DNS: 192.168.225.1	MTU: 1500	Connected Time: 9 minutes 55 seconds	

3.3.1.4.3 Wi-Fi Station status information

The Wi-Fi status page shows the IP address, gateway, and DNS information obtained after the Wi-Fi connection was successful.

WiFi Status

Status: Connected	Interface Name: wlan0	Connected Time: 10 minutes 28 seconds	IP Address: 10.5.62.141
Netmask: 255.255.255.0	Gateway: 10.5.62.254	DNS: 62.139.2.69, 183.221.253.100	MTU: 1500

3.3.1.4.4 DHCP Server status information

The DHCP Server status page shows the assigned IP address of the device as a DHCP Server, the client hostname, the client host mac, and the expiration time.

DHCP Allocation

Hostname	Ip	Mac	Lease Expiration Time
No data			

3.3.1.4.5 Route state information

The route status page displays IPv4 direct route, static route and route neighbor information.

The screenshot shows the Mikrotik Edge Computer System page. The left sidebar has a menu with 'System' selected. The main content area is titled 'Routes' and contains two tables.

Active IPv4 Routes

Interface	Target	IPv4 Gateway	Metric
cellular0	0.0.0.0	192.168.225.1	200
wlan0	0.0.0.0	10.5.62.254	201
wlan0	10.5.62.0/24	-	-
docker0	172.17.0.0/16	-	-
eth1	192.168.3.0/24	-	-
eth2	192.168.4.0/24	-	-
cellular0	192.168.225.0/24	-	-

IPv4 Neighborhoods

IPv4 Address	MAC Address	Interface
192.168.4.199	e454e8d2:1a8e	eth2
192.168.225.1	126b63:7c7c:cb	cellular0
192.168.4.202	266da5b4:48d1	eth2

3.3.1.4.6 Firewall status information

Firewall status information shows filtering rules, IP address mapping rules and other information.

The screenshot shows the Mikrotik Edge Computer System page with the Firewall section selected. The main content area displays the Firewall List and Chain statistics.

Firewall List

Table: Filter

Chain INPUT (Policy: ACCEPT, Packets: 58188, Traffic: 4038K)

Packets	Traffic	Target	Protocol	In	Out	Source Address	Destination Address	Options
101K	61M	ACCEPT	all	lo	-	0.0.0.0/0	0.0.0.0/0	/! fw3 */
111K	11M	input_rule	all	-	-	0.0.0.0/0	0.0.0.0/0	/! fw3: Custom input rule c...
25365	5181K	ACCEPT	all	-	-	0.0.0.0/0	0.0.0.0/0	ctstate RELATED, ESTABLISH...
842	43784	syn_flood	tcp	-	-	0.0.0.0/0	0.0.0.0/0	tcp flags: 0x17/0x02 /! fw3 */

Chain FORWARD (Policy: ACCEPT, Packets: 2, Traffic: 65B)

Packets	Traffic	Target	Protocol	In	Out	Source Address	Destination Address	Options
5	1655	forwarding_rule	all	-	-	0.0.0.0/0	0.0.0.0/0	/! fw3: Custom forwarding ...
0	0	ACCEPT	all	-	-	0.0.0.0/0	0.0.0.0/0	ctstate RELATED, ESTABLISH...

Chain OUTPUT (Policy: ACCEPT, Packets: 459, Traffic: 3855B)

Packets	Traffic	Target	Protocol	In	Out	Source Address	Destination Address	Options
101K	61M	ACCEPT	all	-	lo	0.0.0.0/0	0.0.0.0/0	/! fw3 */
21982	53M	output_rule	all	-	-	0.0.0.0/0	0.0.0.0/0	/! fw3: Custom output rule ...
19251	52M	ACCEPT	all	-	-	0.0.0.0/0	0.0.0.0/0	ctstate RELATED, ESTABLISH...

3.3.1.4.7 Log information

The log page can view the system log, user log and set the log level, including Error, Info, Debug and other levels. Logs can also be downloaded locally.

Level	Time	Content
Info	2023-10-20 08:58:22	base_system[1409]: subscribe topic: nezha/6530bc552ea9f25486d5d36b/cloud/response
Info	2023-10-20 08:58:22	base_system[1409]: subscribe topic: nezha/6530bc552ea9f25486d5d36b/alerts/rules
Info	2023-10-20 08:58:22	base_system[1409]: subscribe topic: \$aws/things/6530bc552ea9f25486d5d36b/shadow/name/+ /delete/accepted
Info	2023-10-20 08:58:22	base_system[1409]: subscribe topic: \$aws/things/6530bc552ea9f25486d5d36b/shadow/name/+ /get/accepted
Info	2023-10-20 08:58:22	base_system[1409]: subscribe topic: \$aws/things/6530bc552ea9f25486d5d36b/shadow/name/+ /update/accepted
Info	2023-10-20 08:58:22	base_system[1409]: subscribe topic: \$aws/things/6530bc552ea9f25486d5d36b/shadow/name/+ /delete/rejected
Info	2023-10-20 08:58:22	base_system[1409]: subscribe topic: \$aws/things/6530bc552ea9f25486d5d36b/shadow/name/+ /get/rejected
Info	2023-10-20 08:58:22	base_system[1409]: subscribe topic: \$aws/things/6530bc552ea9f25486d5d36b/shadow/name/+ /update/rejected
Info	2023-10-20 08:58:22	base_system[1409]: subscribe topic: \$aws/things/6530bc552ea9f25486d5d36b/shadow/name/+ /update/delta
Info	2023-10-20 08:58:22	base_system[1409]: subscribe topic: nezha/6530bc552ea9f25486d5d36b/license
Info	2023-10-20 08:58:22	base_system[1409]: subscribe topic: \$aws/events/thing/6530bc552ea9f25486d5d36b/deleted
Info	2023-10-20 08:58:22	base_system[1409]: subscribe topic: nezha/6530bc552ea9f25486d5d36b/methods/request/*
Info	2023-10-20 08:58:22	base_system[1409]: starting service: shadow
Info	2023-10-20 08:58:22	base_system[1409]: starting service: timeseries
Info	2023-10-20 08:58:22	base_system[1409]: starting service: config
Info	2023-10-20 08:58:22	base_system[1409]: starting service: job
Info	2023-10-20 08:58:22	base_system[1409]: starting service: state
Info	2023-10-20 08:58:22	base_system[1409]: nat firewall rule restart charline

3.3.2 Linux-based command-line management

When using the Linux command line for network and system configuration, the first thing you need to do is close the IEOS program. IEOS is managed through systemctl,

Shutting down IEOS is done as follows:

```
systemctl stop ieos_daemon
```

This shutdown only applies to this startup, and IEOS programs will still start after the system is rebooted. Here's how to prevent IEOS programs from starting:

```
systemctl disable ieos_daemon
```

Important note: After IEOS is closed, wireless networking functions such as dialing and Wi-Fi need to be implemented based on native Linux commands, and it is not possible to interface with the DeviceLive platform to remotely manage devices.

3.3.2.1 Network management

3.3.2.1.1 Set up a static IP address

If you want to set static IP address for EC942, through the command vim/etc/network/interfaces. D/eth1 or vim/etc/network/interfaces. D/for eth2 modify the corresponding network configuration file to the default gateway for Ethernet interface, address, Network and subnet mask. As an example, let's set a static IP address for the eth2 port:

To check the computer firmware version for EC942, type:

```
edge@edge-computer:~$ ecversion
EC942 version V2.0.1-test.2
edge@edge-computer:~$
```

Add the -a option to see the full version information:

```
edge@edge-computer:~$ ecversion -a
EC942 version V2.0.1-test.2 Build 20231018
edge@edge-computer:~$
```

3.3.2.3.2 Viewing available disk space

To determine the amount of available drive space, use the `df` command with the `-h` option. The system will return the amount of drive space broken down by file system. For EC942 products, the disk partition available to the user is `/dev/mmcblk0p8`. Here's an example:

```
edge@edge-computer:~$ df -h
Filesystem      Size  Used Avail Use% Mounted on
/dev/mmcblk0p7  26M   14K   23M   1% /custom
/dev/mmcblk0p8  5.8G  241M  5.2G   5% /userdata
overlay         5.8G  241M  5.2G   5% /
devtmpfs       1.9G   8.0K  1.9G   1% /dev
tmpfs          2.0G   16K   2.0G   1% /tmp
tmpfs          2.0G    0   2.0G   0% /dev/shm
tmpfs          2.0G   18M   1.9G   1% /run
tmpfs          5.0M   4.0K  5.0M   1% /run/lock
tmpfs          2.0G    0   2.0G   0% /sys/fs/cgroup
tmpfs          391M   4.0K  391M   1% /run/user/108
tmpfs          391M   4.0K  391M   1% /run/user/1001
```

3.3.2.3.3 Querying product model information

The `devinfo` tool can view the product model information

```
edge@edge-computer:~$ sudo devinfo
model=EC942
alias=
serialnumber=CL9422343000019
partnumber=LQA8-W-G
```

3.3.2.3.4 Adjust the time

EC942 has two time Settings. One is system time and the other is RTC (Real Time Clock) time, which is maintained by the hardware of the EC942. Use the `date` command to query the current system time or to set a new system time. Use the `hwclock` command to query the current RTC time or set a new RTC time.

Use the command `date MMDDhhmmYYYY` to set the system time:

MM: month

DD: day

hh: hour

mm: a minute

YYYY: Year

```
edge@edge-computer:~$ sudo date 030115052023
Wed Mar  1 15:05:00 CST 2023
```

RTC time can be set to system time using the following command

```
edge@edge-computer:~$ sudo hwclock
2023-03-01 15:05:55.192961+08:00
```

Click on the link below for more details about the date and time:

<https://www.debian.org/doc/manuals/system-administrator/ch-sysadmin-time.html>

<https://wiki.debian.org/DateTime>

3.3.2.3.5 set time zone

There are two ways to configure the time zone for EC942. One is to use the command `tzselect`. The other is to use the `/etc/localtime` file.

3.3.2.3.6 Use the `tzselect` command

When you type the `tzselect` command, you will be taken to the area selection screen. Select the approximate area (divided by continent and ocean) and enter the number in front of the continent or ocean

```
edge@edge-computer:~$ tzselect
Please identify a location so that time zone rules can be set correctly.
Please select a continent, ocean, "coord", or "TZ".
 1) Africa
 2) Americas
 3) Antarctica
 4) Asia
 5) Atlantic Ocean
 6) Australia
 7) Europe
 8) Indian Ocean
 9) Pacific Ocean
10) coord - I want to use geographical coordinates.
11) TZ - I want to specify the time zone using the Posix TZ format.
```

Then select the continent or the country under the ocean

```
#? 4
Please select a country whose clocks agree with yours.
 1) Afghanistan      18) Israel           35) Palestine
 2) Armenia          19) Japan            36) Philippines
 3) Azerbaijan       20) Jordan           37) Qatar
 4) Bahrain          21) Kazakhstan      38) Russia
 5) Bangladesh       22) Korea (North)   39) Saudi Arabia
 6) Bhutan           23) Korea (South)   40) Singapore
 7) Brunei           24) Kuwait          41) Sri Lanka
 8) Cambodia         25) Kyrgyzstan      42) Syria
 9) China            26) Laos            43) Taiwan
10) Cyprus           27) Lebanon         44) Tajikistan
11) East Timor       28) Macau           45) Thailand
12) Georgia          29) Malaysia        46) Turkmenistan
13) Hong Kong        30) Mongolia        47) United Arab Emirates
14) India            31) Myanmar (Burma) 48) Uzbekistan
15) Indonesia        32) Nepal           49) Vietnam
16) Iran             33) Oman            50) Yemen
17) Iraq             34) Pakistan
```

Follow the steps above to get the China time zone keyword Asia/Shanghai and execute the following command to set the time zone

```
#? 9
Please select one of the following time zone regions.
1) Beijing Time
2) Xinjiang Time
#? 1

The following information has been given:

    China
    Beijing Time

Therefore TZ='Asia/Shanghai' will be used.
Selected time is now:  Wed Mar  1 15:07:31 CST 2023.
Universal Time is now:  Wed Mar  1 07:07:31 UTC 2023.
Is the above information OK?
1) Yes
2) No
#? Yes
Please enter a number in range.
#? 1

You can make this change permanent for yourself by appending the line
    TZ='Asia/Shanghai'; export TZ
to the file '.profile' in your home directory; then log out and log in again.

Here is that TZ value again, this time on standard output so that you
can use the /usr/bin/tzselect command in shell scripts:
Asia/Shanghai
```

3.3.2.3.7 Using localtime files

The localtime zone is stored in `/etc/localtime` and is used by the GNU library for C (glibc) if no value is set for the TZ environment variable. This file is either a copy of `/usr/share/zoneinfo/file` or a symbolic link to it. If EC942 cannot find `/usr/share/zoneinfo/file`, please download from the web site you need the time zone information file (<https://www.iana.org/time-zones>), and links to the local time in the EC900 file.

Note

After successfully downloading the required time zone information file, unzip it, and then compile and generate the corresponding binary file using `zic` command. The generated time zone file is `"/usr/share/zoneinfo/custom time zone filename"`.

Advanced configuration of peripheral interfaces

In this chapter, we will introduce the advanced configuration of peripheral interfaces for EC900, an edge computer based on Arm architecture.

4.1 Serial Port

EC942 has 2 serial ports, each of which supports RS-232, RS-422 and RS-485 multiple serial port modes. The default serial port mode is RS-232, and the serial port mode can be switched by using `ih_uart_ctl` command.

The device node corresponding to COM1 is `/dev/ttyS3`

The device node for COM2 is `/dev/ttyS4`

```
edge@edge-computer:~$ sudo ih_uart_ctl --help
Usage:
  ih_uart_ctl [OPTIONS]

OPTIONS
  help          Help info of how to use ih_uart_ctl command.

  port_num=<num>    num:0,1
                   0 → /dev/ttyS3
                   1 → /dev/ttyS4
                   show the port mode
                   example: ih_uart_ctl port_num=0

  uart_mode=<num>   num:0,1,2
                   0 → RS232
                   1 → RS485
                   2 → RS422
                   set the uart port mode
                   if you do not input port number, the default port n
um is 0
                   example: ih_uart_ctl uart_mode=0
                   example: ih_uart_ctl port_num=0 uart_mode=0
```

4.1.1 Change the serial port Settings

View and set the serial port with the stty command

To see the details, type `sudo stty --help`:

```

edge@edge-computer:~$ sudo stty --help
Usage: stty [-F DEVICE | --file=DEVICE] [SETTING] ...
  or: stty [-F DEVICE | --file=DEVICE] [-a|--all]
  or: stty [-F DEVICE | --file=DEVICE] [-g|--save]
Print or change terminal characteristics.

Mandatory arguments to long options are mandatory for short options too.
-a, --all          print all current settings in human-readable form
-g, --save        print all current settings in a stty-readable form
-F, --file=DEVICE open and use the specified DEVICE instead of stdin
--help           display this help and exit
--version        output version information and exit

Optional - before SETTING indicates negation. An * marks non-POSIX
settings. The underlying system defines which settings are available.

Special characters:
* discard CHAR    CHAR will toggle discarding of output
eof CHAR         CHAR will send an end of file (terminate the input)
eol CHAR         CHAR will end the line
* eol2 CHAR       alternate CHAR for ending the line
erase CHAR       CHAR will erase the last character typed
intr CHAR        CHAR will send an interrupt signal
kill CHAR        CHAR will erase the current line
* lnext CHAR      CHAR will enter the next character quoted
quit CHAR        CHAR will send a quit signal
* rprint CHAR     CHAR will redraw the current line
start CHAR       CHAR will restart the output after stopping it
stop CHAR        CHAR will stop the output
susp CHAR        CHAR will send a terminal stop signal
* swtch CHAR      CHAR will switch to a different shell layer
* werase CHAR     CHAR will erase the last word typed

Special settings:
N                set the input and output speeds to N bauds
* cols N         tell the kernel that the terminal has N columns
* columns N      same as cols N
* [-]drain       wait for transmission before applying settings (on by default)
ispeed N        set the input speed to N
* line N         use line discipline N
min N           with -icanon, set N characters minimum for a completed read
ospeed N        set the output speed to N
* rows N         tell the kernel that the terminal has N rows
* size           print the number of rows and columns according to the kernel
speed           print the terminal speed
time N          with -icanon, set read timeout of N tenths of a second

Control settings:
[-]clocal       disable modem control signals
[-]cread        allow input to be received
* [-]crtstcts   enable RTS/CTS handshaking
csN             set character size to N bits, N in [5..8]
[-]cstopb      use two stop bits per character (one with '-')
[-]hup         send a hangup signal when the last process closes the tty
[-]hupcl       same as [-]hup

[-]parenb      generate parity bit in output and expect parity bit in input
[-]parodd      set odd parity (or even parity with '-')
* [-]cmspar     use "stick" (mark/space) parity

```

```

Input settings:
[-]brkint      breaks cause an interrupt signal
[-]icrnl      translate carriage return to newline
[-]ignbrk     ignore break characters
[-]igncr      ignore carriage return
[-]ignpar     ignore characters with parity errors
* [-]imaxbel  beep and do not flush a full input buffer on a character
[-]inlcr     translate newline to carriage return
[-]inpck     enable input parity checking
[-]istrip    clear high (8th) bit of input characters
* [-]iutf8    assume input characters are UTF-8 encoded
* [-]iuclc    translate uppercase characters to lowercase
* [-]ixany    let any character restart output, not only start character
[-]ixoff     enable sending of start/stop characters
[-]ixon      enable XON/XOFF flow control
[-]parmrk    mark parity errors (with a 255-0-character sequence)
[-]tandem    same as [-]ixoff

Output settings:
* bsN        backspace delay style, N in [0..1]
* crN        carriage return delay style, N in [0..3]
* ffN        form feed delay style, N in [0..1]
* nlN        newline delay style, N in [0..1]
* [-]ocrnl   translate carriage return to newline
* [-]ofdel   use delete characters for fill instead of NUL characters
* [-]ofill   use fill (padding) characters instead of timing for delays
* [-]olcuc   translate lowercase characters to uppercase
* [-]onlcr   translate newline to carriage return-newline
* [-]onlret  newline performs a carriage return
* [-]onocr   do not print carriage returns in the first column
[-]opost     postprocess output
* tabN      horizontal tab delay style, N in [0..3]
* tabs      same as tab0
* -tabs     same as tab3
* vtN      vertical tab delay style, N in [0..1]

Local settings:
[-]crterase  echo erase characters as backspace-space-backspace
* crtkill    kill all line by obeying the echoprnt and echoe settings
* -crtkill   kill all line by obeying the echoctl and echok settings
* [-]ctlecho echo control characters in hat notation ('^c')
[-]jecho     echo input characters
* [-]echoctl same as [-]ctlecho
[-]jechoe    same as [-]crterase
[-]jechok    echo a newline after a kill character
* [-]jechoke same as [-]crtkill
[-]jechonl   echo newline even if not echoing other characters
* [-]echoprnt echo erased characters backward, between '\' and '/'
* [-]extproc  enable "LINEMODE"; useful with high latency links
* [-]flusho  discard output
[-]icanon    enable special characters: erase, kill, werase, rprnt
[-]ixexten   enable non-POSIX special characters
[-]isig      enable interrupt, quit, and suspend special characters

[-]noflsh    disable flushing after interrupt and quit special characters
* [-]prterase same as [-]echoprnt
* [-]tostop  stop background jobs that try to write to the terminal
* [-]xcase   with icanon, escape with '\' for uppercase characters

```



```

Combination settings:
* [-]LCASE      same as [-]lcase
cbreak         same as -icanon
-cbreak        same as icanon
cooked         same as brkint ignpar istrip icrnl ixon opost isig
               icanon, eof and eol characters to their default values
-ccooked       same as raw
crt            same as echoe echoctl echoke
dec           same as echoe echoctl echoke -ixany intr ^c erase 0177
               kill ^u
* [-]decctlq   same as [-]ixany
ek            erase and kill characters to their default values
evenp         same as parenb -parodd cs7
-evenp        same as -parenb cs8
* [-]lcase     same as xcase iuclc olcuc
litout        same as -parenb -istrip -opost cs8
-litout       same as parenb istrip opost cs7
nl            same as -icrnl -onlcr
-nl           same as icrnl -inlcr -igncr onlcr -ocrnl -onlret
oddp          same as parenb parodd cs7
-oddp         same as -parenb cs8
[-]parity     same as [-]evenp
pass8         same as -parenb -istrip cs8
-pass8        same as parenb istrip cs7
raw           same as -ignbrk -brkint -ignpar -parmrk -inpck -istrip
               -inlcr -igncr -icrnl -ixon -ixoff -icanon -opost
               -isig -iuclc -ixany -imaxbel -xcase min 1 time 0
-raw          same as cooked
sane          same as cread -ignbrk brkint -inlcr -igncr icrnl
               icanon iexten echo echoe echok -echonl -noflsh
               -ixoff -iutf8 -iuclc -ixany imaxbel -xcase -olcuc -ocrnl
               opost -ofill onlcr -onocr -onlret -ofill -ofdel n10 cr0 tab0 bs0 vt0 ff0
               isig -tostop -ofdel -echoprt echoctl echoke -extproc -flusho,
               all special characters to their default values

Handle the tty line connected to standard input. Without arguments,
prints baud rate, line discipline, and deviations from stty sane. In
settings, CHAR is taken literally, or coded as in ^c, 0x37, 0177 or
127; special values ^- or undef used to disable special characters.

GNU coreutils online help: <https://www.gnu.org/software/coreutils/>
Report stty translation bugs to <https://translationproject.org/team/>
Full documentation at: <https://www.gnu.org/software/coreutils/stty>
or available locally via: info '(coreutils) stty invocation'

```

4.1.2 View serial port information:

```

edge@edge-computer:~$ sudo stty -a -F /dev/ttyS3
speed 9600 baud; rows 0; columns 0; line = 0;
intr = ^C; quit = ^\; erase = ^?; kill = ^U; eof = ^D; eol = <undef>;
eol2 = <undef>; swtch = <undef>; start = ^Q; stop = ^S; susp = ^Z; rprnt = ^R;
werase = ^W; lnext = ^V; discard = ^O; min = 1; time = 0;
-parenb -parodd -cmspar cs8 hupcl -cstopb cread clocal -crtcts
-ignbrk -brkint -ignpar -parmrk -inpck -istrip -inlcr -igncr icrnl ixon -ixoff
-iuclc -ixany -imaxbel -iutf8
opost -olcuc -ocrnl onlcr -onocr -onlret -ofill -ofdel n10 cr0 tab0 bs0 vt0 ff0
isig icanon iexten echo echoe echok -echonl -noflsh -xcase -tostop -echoprt echoctl
echoke -flusho -extproc

```

4.1.3 Set the baud rate of COM1 serial port:

```
edge@edge-computer:~$ sudo stty -F /dev/ttyS3 ispeed 9600 ospeed 9600 cs8
```

4.1.4 Set the baud rate of COM2 serial port

```
edge@edge-computer:~$ sudo stty -F /dev/ttyS4 ispeed 9600 ospeed 9600 cs8
```

Note

Details about the stty command are available at the following link

<http://www.gnu.org/software/coreutils/manual/coreutils.html>

4.2 the USB interface

EC942 provides two USB 2.0 Host interfaces, which are mainly used to expand storage devices and connect to mice and keyboards

4.2.1 USB auto-mount

EC942 supports USB storage device hotplugging. It will mount all partitions automatically. EC942 will mount all USB storage device partitions to the /mnt/ path with the mount folder named usb_<node>_<num>. Where <node> is the device node name of the partition, and <num> can be a number from 0 to 9.

```
edge@edge-computer:~$ sudo mount|grep "/mnt"
overlay on /mnt type overlay (rw,relatime,lowerdir=/mnt,upperdir=/userdata/v1//mnt_
rw/upper,workdir=/userdata/v1//mnt_rw/work)
/dev/sda1 on /mnt/usb_sda1_0 type vfat (rw,nodev,noatime,fmask=0022,dmask=0022,code
page=936,ioccharset=cp936,shortname=mixed,errors=remount-ro)
```

Note

Remember to enter the sync sync command before disconnecting your USB mass storage device to prevent data loss. When you disconnect your storage device, exit from the /media/* directory. If you stay in /media/usb*, the automatic uninstall process will fail. If this happens, type umount /media/usb* to manually unmount the device

4.2.2 micro SD card mounts automatically

EC942 supports micro SD memory card but does not support hotplugging. It will mount all partitions automatically. EC942 will mount all micro SD memory card partitions to the /mnt/ path with the mount folder named sd_<node>_<num>. Where <node> is the device node name of the partition, and <num> is a number from 0 to 9.

```
edge@edge-computer:~$ df -h
Filesystem      Size  Used Avail Use% Mounted on
/dev/root        3.5G  2.7G  566M  83% /
devtmpfs        1.9G  8.0K  1.9G   1% /dev
/dev/mmcblk0p9  8.2G  473M  7.8G   6% /userdata
overlay         8.2G  473M  7.8G   6% /var
overlay         8.2G  473M  7.8G   6% /etc
overlay         8.2G  473M  7.8G   6% /home
overlay         8.2G  473M  7.8G   6% /root
overlay         8.2G  473M  7.8G   6% /sbin
overlay         8.2G  473M  7.8G   6% /bin
overlay         8.2G  473M  7.8G   6% /usr
overlay         8.2G  473M  7.8G   6% /lib
overlay         8.2G  473M  7.8G   6% /tmp
overlay         8.2G  473M  7.8G   6% /mnt
overlay         8.2G  473M  7.8G   6% /opt
overlay         8.2G  473M  7.8G   6% /media
overlay         8.2G  473M  7.8G   6% /system
overlay         8.2G  473M  7.8G   6% /boot
overlay         8.2G  473M  7.8G   6% /srv
overlay         8.2G  473M  7.8G   6% /vendor
tmpfs           1.9G   32K  1.9G   1% /dev/shm
tmpfs           1.9G   8.9M  1.9G   1% /run
tmpfs           5.0M   4.0K  5.0M   1% /run/lock
tmpfs           1.9G    0  1.9G   0% /sys/fs/cgroup
/dev/mmcblk0p7  126M   13M  107M  11% /oem
/dev/mmcblk1p2  3.7G  800M  2.8G  23% /mnt/sd_mmcblk1p2_0
/dev/mmcblk1p1  69M   26M   44M  37% /mnt/sd_mmcblk1p1_0
tmpfs           378M    0  378M   0% /run/user/108
tmpfs           378M    0  378M   0% /run/user/1001
```

4.2.3 mSATA hard disk mounts automatically

(1) Log in to the system, run `sudo fdisk -l`, find your hard disk partition, as shown below is `/dev/sda1`

```
edge@edge-computer:~$ sudo fdisk -l
Disk /dev/ram0: 4 MiB, 4194304 bytes, 8192 sectors
Units: sectors of 1 * 512 = 512 bytes
Sector size (logical/physical): 512 bytes / 4096 bytes
I/O size (minimum/optimal): 4096 bytes / 4096 bytes

Disk /dev/sda: 119.2 GiB, 128035676160 bytes, 250069680 sectors
Disk model: Lenovo SSD SL700
Units: sectors of 1 * 512 = 512 bytes
Sector size (logical/physical): 512 bytes / 512 bytes
I/O size (minimum/optimal): 512 bytes / 512 bytes
Disklabel type: dos
Disk identifier: 0x1a63708d

Device            Boot Start          End      Sectors   Size Id Type
/dev/sda1         2048 250069679 250067632 119.2G 83 Linux

Disk /dev/mmcblk0: 14.6 GiB, 15634268160 bytes, 30535680 sectors
Units: sectors of 1 * 512 = 512 bytes
Sector size (logical/physical): 512 bytes / 512 bytes
I/O size (minimum/optimal): 512 bytes / 512 bytes
Disklabel type: gpt
Disk identifier: 902C0000-0000-4864-8000-6B9300002304

Device            Start          End      Sectors   Size Type
/dev/mmcblk0p1    16384         24575      8192      4M unknown
/dev/mmcblk0p2    24576         32767      8192      4M unknown
/dev/mmcblk0p3    32768         98303    65536     32M unknown
/dev/mmcblk0p4    98304        163839    65536     32M unknown
/dev/mmcblk0p5    163840       229375    65536     32M unknown
/dev/mmcblk0p6    229376      10715135 10485760    5G unknown
/dev/mmcblk0p7   10715136    10977279    262144    128M unknown
/dev/mmcblk0p8   10977280    13074431    2097152     1G unknown
/dev/mmcblk0p9   13074432    30535615   17461184    8.3G unknown
```

Format the partition to the desired filesystem, such as `ext4`

```

edge@edge-computer:~$ sudo mkfs.ext4 /dev/sda1
mke2fs 1.44.5 (15-Dec-2018)
Discarding device blocks: done
Creating filesystem with 31258454 4k blocks and 7815168 inodes
Filesystem UUID: 59e1a7cf-0044-4453-9886-518aee27fc2a
Superblock backups stored on blocks:
    32768, 98304, 163840, 229376, 294912, 819200, 884736, 1605632, 2654208,
    4096000, 7962624, 11239424, 20480000, 23887872

Allocating group tables: done
Writing inode tables: done
Creating journal (131072 blocks): done
Writing superblocks and filesystem accounting information: done

```

Create a mount point such as /mnt/sda1

(4) Edit vi /etc/fstab file,

Add /dev/sda1/mn/sda1 ext4 defaults,nofail,x-systemd.device-timeout=1s 0 0 to the end line, as shown below:

/dev/sda1: device partition, which needs to be configured by the user according to the actual situation

/mnt/sda1: mount point, which needs to be configured according to the actual situation

ext4 hard disk partition file system format, users need to configure according to the actual situation

defaults,nofail,x-systemd.device-timeout=1s 0 0 Fixed configuration, which is recommended, but can be modified as needed.

```

UNCONFIGURED FSTAB FOR BASE SYSTEM
/dev/mmcblk0p7 /oem ext2 defaults 0 0
#/dev/mmcblk0p8 /userdata ext2 defaults 0 0
/dev/sda /mnt/sda ext4 defaults,nofail,x-systemd.device-timeout=60s 0 0
~

```

4.3 CAN bus interface

The CAN port of the EC942 supports the CAN bus.

4.3.1 Configure the connection CAN interface

By default, the CAN port will be initialized. If you need any other configuration, check the CAN device using the ip link command. To check the status of the CAN device, use the ip link command:

```

2: can0: <NOARP,ECHO> mtu 16 qdisc noop state DOWN mode DEFAULT group default qlen 10
   link/can

```

To configure the CAN device, use ip link set can0 down to turn the device off first

```

edge@edge-computer:~$ sudo ip link set can0 down

```

Then configure the bit rate (here's a 50k bit rate example) :

```
edge@edge-computer:~$ sudo ip link set can0 type can bitrate 50000 dbitrate 50000 f
d on
```

Finally turn the device back on

```
edge@edge-computer:~$ sudo ip link set can0 up
```

4.4 IO Debugging

The EC942 supports 4-way DI and 4-way DO. When you want to use IO port, please type `dio_mgmt` command to control io input and output. Usage of `dio_mgmt`:

```
edge@edge-computer:~$ sudo dio_mgmt
Usage:
  dio_mgmt <OPTIONS>

OPTIONS
  help                Help info of how to use dio_mgmt.
  show <DI0|DI1|DI2|DI3|DO0|DO1|DO2|DO3>
                     Show the status of digital IO.
  set <DO0|DO1|DO2|DO3> <LOW|HIGH>
                     Set the status of digital out IO.
```

`dio_mgmt set D<I/O><number><HIGH/LOW>` When you need to set a bit of IO port to high or low, type `dio_mgmt set d <I/O><number>< high/low >`

```
edge@edge-computer:~$ sudo dio_mgmt set DO3 LOW
edge@edge-computer:~$ sudo dio_mgmt show DI0
LOW
```

Print the corresponding IO level information by typing `dio_mgmt show D<I/O><number>`.

4.5 GPS

Some models of EC900 are integrated with GPS module, and the data serial port node is `/dev/ttyS9`.

If you want to view the details of the GPS, there are two ways to view it:

1. Use `stty` to set up the serial port node and type `cat` to output the source data directly

```
edge@edge-computer:~$ sudo stty -F /dev/ttyS9 ispeed 115200 ospeed 1115200 cs8
edge@edge-computer:~$ cat /dev/ttyS9
$GNGGA,,,,,0,00,25.5,,,,,*64
$GNGLL,,,,,V,N*7A
$GPGSA,A,1,,,,,,,,,,,,,25.5,25.5,25.5*02
$BDGSA,A,1,,,,,,,,,,,,,25.5,25.5,25.5*13
$GLGSA,A,1,,,,,,,,,,,,,25.5,25.5,25.5*1E
$GPGSV,1,1,01,193,,,17*45
$BDGSV,1,1,00*68
$GLGSV,1,1,02,78,,,37,70,,,39*61
$GNRMC,,V,,,,,,,,,N*4D
$GNVTG,,,,,,,,,N*2E
$GNZDA,,,,,*56
$GPTXT,01,01,01,ANTENNA OPEN*25
$GNGGA,,,,,0,00,25.5,,,,,*64
```

2. Typing `gnss` commands directly outputs the parsed time, latitude and longitude, and other information

```
edge@edge-computer:~$ sudo gnss
```

4.6 Toggle the machine button

4.6.1 Turn off the device

1. Turn off the device by long pressing the on/off button for 8 seconds
2. You can use Linux commands to shut down all software running on the device and stop the system. However, after running this command, major components such as CPU, RAM, and storage devices will lose power.

```
edge@edge-computer:~$ sudo shutdown -h now
```

4.6.2 Boot the device

Press the on/off button, and the system will perform the boot operation.

5 Safety

In this chapter, we will introduce the security mechanism of EC900, an edge computer based on ARM architecture.

5.1 sudo mechanism

In EC900, the root user is banned for better security. Sudo is a program that lets the system administrator allow an approved user to execute some commands as the root user or another user. The most basic rule is to give as few privileges as possible to get the job done. Using sudo is more secure than root session opening for a number of reasons, including:

- Grant privileges to normal users without having to know the root password (sudo will prompt for the current user's password)
- It's easy to run privileged commands via sudo, and the rest of the time, work as an unprivileged user, reducing potential damage due to wrong operations.
- Some system-level commands are not available directly to the user, as shown in the following example output:

```

edge@edge-computer:~$ ifconfig
-bash: ifconfig: command not found
edge@edge-computer:~$ sudo ifconfig
br-97e4c72399e1: flags=4163<UP,BROADCAST,RUNNING,MULTICAST> mtu 1500
    inet 172.18.0.1 netmask 255.255.0.0 broadcast 172.18.255.255
    inet6 fe80::42:eff:fe07:c8aa prefixlen 64 scopeid 0x20<link>
    ether 02:42:0e:07:c8:aa txqueuelen 0 (Ethernet)
    RX packets 663 bytes 81645 (79.7 KiB)
    RX errors 0 dropped 0 overruns 0 frame 0
    TX packets 595 bytes 107290 (104.7 KiB)
    TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0

docker0: flags=4099<UP,BROADCAST,MULTICAST> mtu 1500
    inet 172.17.0.1 netmask 255.255.0.0 broadcast 172.17.255.255
    ether 02:42:c4:58:eb:69 txqueuelen 0 (Ethernet)
    RX packets 0 bytes 0 (0.0 B)
    RX errors 0 dropped 0 overruns 0 frame 0
    TX packets 0 bytes 0 (0.0 B)
    TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0

```

5.2 Firewalls

Netfilter/iptables is an excellent and free firewall tool based on packet filtering which comes with nix/linux system. It is very powerful and flexible, and can control the data packets flowing in, out and through the server in fine detail.

5.3 TPM2.0

TPM stands for "Trusted Platform Module" and it is a hardware security module designed to provide security and encryption capabilities for computer systems. It is a secure microcontroller that can be embedded in a computer system or sold as a standalone hardware device. It contains a cryptographic coprocessor for storing encryption keys, digital certificates, and other secure data, as well as supporting multiple cryptographic algorithms and security protocols. On EC942, the standard TPM2.0 protocol stack and TPM2.0 tools have been integrated for user use.

6 The system restores factory Settings and updates

In this chapter, we will describe how EC900, an edge computer based on Arm architecture, restores factory Settings and updates.

6.1 Restore factory Settings

There are two ways to restore factory Settings:

1. By typing the command, the system will automatically restart and restore the factory Settings.

```
edge@edge-computer:~$ sudo update reset
```

2. Restore factory Settings by pressing:
 4. Long press the restore factory Settings button for 10-20s and see the warn light long on.
 5. When the warn light has turned on, release the Restore Factory Settings button.

6. After releasing the Restore Factory Settings button, the error light blinks several times before the system starts to restart and perform Restore Factory Settings
7. After the system restarts, the warn light and error light will flash, and status will be off; After about 30s, when both warn light and error light stop flashing and status starts flashing at the same time, the system is finished restoring the factory Settings.

6.2 System Upgrades

Get a USB key (micro SD card). If the USB key (SD card) has multiple partitions, use the first partition. It is recommended not to make multiple partitions. Usb key (SD card) partitions need to be formatted in FAT32 format. This document takes upgrading EC942-V2.0.0.img as an example to explain.

5. Create an empty ec900_img directory in the root directory of the U disk (SD card), and put the EC942-V2.0.0.img file and md5.txt file published by inhand into the ec900_img directory.
6. Make sure that the MD5.txt file only has the md5 hash value of EC942-V2.0.0.img line. EC942 does not support ota upgrade of multiple img images.
7. Exit the USB flash drive (SD card) normally on the computer. Be careful not to unplug the USB key directly, but to select the "Exit" or "eject" action from the desktop.
8. Insert the USB key (SD card) into the target EC900 device. The target device will automatically verify the EC942-V2.0.0.img file and perform OTA upgrade. The WARN and ERROR lights will be displayed accordingly during the upgrade. When WARN and ERROR return to normal, the upgrade operation is complete. Because the img file is large, it will take a long time to upgrade. Please wait patiently.
9. After the upgrade, EC900 will write the key information in the upgrade to the log file in the ec900_img directory. Please check the related files.

7 Programming Guidelines

EC900 provides a device information description file in JSON format. Customers who need to operate IO, LED, serial port and other peripherals can obtain the device node information of these peripherals by querying the device description information file.

Device description file path: /tmp/ieos/etc/system_info.json, the content is as follows:

```
{
  "device_info":{
"model_info":{
"model": "EC942
",      "pn": "LQA8-W-G",
        "sn": "CL9422343000019",
"oem": "inhand",
```



```
"features":"; std; cell-LQA8; wlan; io; tmp2;"
},
"software_info":{
"boot_loader":"1.0.1", "kernel
":"4.19.232",
"version":"V2.0.1-test.2",
"OS":"Debian GNU/Linux 10 (buster)"
},
  "hardware_info":{
"arch":"arm64",
"soc":"rk3568",
  "interface":{
"eth":[
{
"iface_name":"eth2",
  "iface_mac":"2E:62:32:7B:B5:28"
},
  {
"iface_name":"eth1",
  "iface_mac":"2A:62:32:7B:B5:28"
}
],
  "wlan":[
{
"iface_name":"wlan0",
  "iface_mac":"88:12:AC:FA:AD:53"
},
  {
"iface_name":"wlan1",
  "iface_mac":"8A:12:AC:FA:AD:53"
}
]
},
  "gpio":[
{
"gpio_name":"cellular_power",
  "dev_node":"/sys/class/gpio/gpio0"
},
  {
"gpio_name":"sim_switch",
  "dev_node":"/sys/class/gpio/gpio19"
},
  {
```

```

"gpio_name":"msata_power",
  "dev_node":"/sys/class/gpio/gpio20"
},
{
  "gpio_name":"gnss_power",
  "dev_node":"/sys/class/gpio/gpio110"  },
{
  "gpio_name":"ble_power",
  "dev_node":"/sys/class/gpio/gpio220"  }  ],

"user_key":[
  {
    "user_key_name":"USER",
    "dev_node":"/sys/class/gpio/gpio95"  }  ],

"uart":[
  {
    "uart_name":"COM1",
    "dev_node":"/dev/ttyS3"  },
  {
    "uart_name":"COM2",
    "dev_node":"/dev/ttyS4"  }  ],

"io":{
  "di":[
    {
      "di_name":"DI1",
      "dev_node":"/sys/class/gpio/gpio487"  },
    {
      "di_name":"DI2",
      "dev_node":"/sys/class/gpio/gpio488"  },
    {
      "di_name":"DI3",
      "dev_node":"/sys/class/gpio/gpio489"  },
    {
      "di_name":"DI4",

```

```

        "dev_node":"/sys/class/gpio/gpio490"    }    ],
    "do":[
    {
        "di_n
ame":"DO1",
        "dev_node":"/sys/class/gpio/gpio491"    },
    {
        "di_name":"DO2
",
        "dev_node":"/sys/class/gpio/gpio492"    },
    {
        "di
_name":"DO3",
        "dev_node":"/sys/class/gpio/gpio493"    },
    {
        "di_name":"DO4",
        "dev_node":"/sys/class/gpio/gpio494"    }    ]    },
    "led":[
    {
        "led_name"
:"USER1",
        "dev_node":"/sys/class/leds/user1"    },
    {
        "led_name"
:"USER2",
        "dev_node":"/sys/class/leds/user2"    },
    {
        "
led_name":"4G/5G",
        "dev_node":"/sys/class/leds/cell"    },
    {
        "l
ed_name":"SIM1",
        "dev_node":"/sys/class/leds/sim1"    },
    {
        "le
d_name":"SIM2",
        "dev_node":"/sys/class/leds/sim2"    },

```

```

    {
      "led_name": "WARN",
      "dev_node": "/sys/class/leds/warn"
    },
    {
      "led_name": "ERROR",
      "dev_node": "/sys/class/leds/error"
    },
    {
      "led_name": "STATUS",
      "dev_node": "/sys/class/leds/status"
    },
    {
      "led_name": "L1",
      "dev_node": "/sys/class/leds/level1"
    },
    {
      "led_name": "L2",
      "dev_node": "/sys/class/leds/level2"
    },
    {
      "led_name": "L3",
      "dev_node": "/sys/class/leds/level3"
    }
  ]
}

```

A guide to IO Programming

Currently, there are a total of 8 IO interfaces on the device: for example, there are 4 input pins from DI0 to DI3 on the device panel; Do0-do3 are 4 output pins.

The IO device nodes can be obtained from the device description file `/tmp/ieos/etc/system_info.json` as follows:

DI0~DI3-----**sys/class/gpio/gpio487~sys/class/gpio/gpio490**

DO0~DO3-----**sys/class/gpio/gpio491~sys/class/gpio/gpio494**

When you need to programming IO interface, direct manipulation background device nodes below the value value (**sys/class/gpio/gpioxxx/value**)

Case study:

When DO0 need to output high electricity at ordinary times, can be directly to **sys/class/gpio/gpio491 / value**

```
echo 1 > /sys/class/gpio/gpio491/value
```

When you need to check **the** DI0 level is, the same can be directly to check **the sys/class/gpio/gpio487 / the value of the value**

```
cat /sys/class/gpio/gpio487/value
```

The full shell script:

7.2 Led Programming Guide

On the device, the user can use the two lights USER1 and USER2 to indicate the status. Please check the lamp label to confirm the position of the two lights USER1 and USER2.

According to the device description file /tmp/ieos/etc/system_info.json, the device nodes of USER1 and USER2 can be obtained as:

```
user1: /sys/class/leds/user1
```

```
user2: /sys/class/leds/user2
```

There are some control files in /sys/class/leds/user1 to control the attributes and status of leds:

/ sys/class/leds/user1 / brightness: this file is used to control the user1 lights on or off. Write 1 to always on, write 0 to always off.

/ sys/class/leds/user1 / trigger: leds trigger, can write the timer timer trigger, write none said cancel the trigger.

/ sys/class/leds/user1 / delay_on: it is time to file said led lights, is an unit with ms.

/ sys/class/leds/user1 / delay_off: it is time to file said led lights, is an unit with ms.

If trigger is configured for timing, the value in the brightness will no longer take effect and will automatically change to 0.

To control the brightness of user2, replace user1 with USER2 in the file path.

Example:

Write 1 to the brightness file when you need the USER1 light to be on

```
echo 1 > /sys/class/leds/user1/brightness
```

When the USER1 light is needed to flash, write the timer to the trigger file and control the time of light and off by delay_on and delay_off

```
Echo # start timer timer > / sys/class/leds light
echo 1 seconds/user1 / trigger

# > 1000 / sys/class/leds/user1 / delay_on echo out

# 1 seconds
1000 > /sys/class/leds/user1/delay_off
```

Full shell script:

7.3 Cross-compilation

A user's own c/ C ++ program can be cross-compiled by using the cross-compilation toolchain on the development machine, and then the object file is uploaded to the EC942 device for execution.

Cross-compiler package: gcc-linaro-6.3.1-2017.05-x86_64_aarch64-linux-gnu.tar.gz

Here's how to configure the environment variables for the cross-compilation toolchain:

1. Unzip gcc-linaro-6.3.1-2017.05-x86_64_aarch64-linux-gnu.tar.gz to /opt on your development machine (you can also unzip it to any other PATH, adjust the path environment variable in step 2)
2. Edit the ~/.bashrc file and add a line PATH=\$PATH:/opt/gcc-linaro-6.3.1-2017.05-x86_64_aarch64-linux-gnu/bin at the end of the file
3. Execute source ~/.bashrc to make the environment variables work in the current terminal; The newly opened terminal will take effect automatically.

Using the classic hello world program as an example, create the following directories and files

```
mkdir ~/example
touch ~/example/hello.c
touch ~/example/Makefile
```

The contents of the ~/example/hello.c file are as follows:

```
#include <stdio.h>

int main(void)
{
    printf("hello, world! \n");
    return 0;
}
```

The contents of the ~/example/Makefile are as follows:

```
# Define TARGET and source filenames
target := helloworld
DIRS := $(shell find.-maxdepth 3-type d)
SRCS := $(foreach dir,$(DIRS),$(wildcard $(dir)/*.c))
OBJS := $(SRCS:.c=.o)

CC=aarch64-linux-gnu-gcc

# Define compiler and compile options
CFLAGS := -Wall-Wextra -g-wno-unused-parameters

# define default TARGET
all: $(TARGET)

# define target file dependencies and compile commands
$(TARGET): $(OBJS)
$(CC) $(CFLAGS) $(LIBS) $^ -o $@

# Define the command to compile the source file to the target file
%.o: %.c
$(CC) $(CFLAGS) $(LIBS) -C $< -o $@

# Define command to clear temporary files
clean:
rm -f $(TARGET) $(OBJS)

# declare pseudo target ".PHONY"
.PHONY: all clean
```

Run make in the ~/example directory to generate the object file helloworld

https://support.inhandnetworks.com/portal/en/kb/articles/ec900#1_Introduction